

**CHANGE NIGHTLIGHT SETTINGS**

When you have selected the nightlight icon, press OK to enter the nightlight menu.

**BRIGHTNESS**

- Press OK to change the brightness setting.
 - Select the preferred brightness with UP/DOWN and confirm with OK.
- Note** Low brightness will lengthen the battery life when using batteries.

**AUTO SHUT-OFF**

- Press OK to change setting.
- Select the preferred timer with UP/DOWN (5-15-30-60 minutes or CONT for the entire night) and confirm with OK.

Note Short timer will lengthen the battery life when using batteries.

**PLAY DEMO-FUNCTION**

- Press OK to enter the demo function mode.
- Press OK to start the demo.
- Sam will now show a sample night from bedtime to OK to get up in the morning.

**SET NAPTIMER**

- Press OK to enter the naptimer menu.
- Select the # minutes you want Sam to sleep (30-180 minutes).
- Press OK to confirm.
- Sam will now go to sleep and wake up after the specified # minutes.

Note To manually open Sam's eyes: unlock keylock and press the UP button for 3 seconds.

**Exit menu**

Leave the menu by pressing the M button.

GENERAL INFORMATION**POWER SUPPLY**

- Sam operates both on AC/DC (adaptor included) and batteries (4x 1.5 V, not included)
- When using batteries we advise you to set the nightlight on 5 minutes timer and use low brightness for longer battery life. Other settings lower battery life significantly.
- When using the nightlight for a longer period, we advise to use the adaptor.
- The batteries will NOT be charged by the adaptor. You can use rechargeable batteries you charge yourself.
- We advise you to insert batteries even though you will use the adaptor, so that in the event of loss of power you will not lose the clock settings.

BATTERY EMPTY

When using batteries, in the centre of the LCD screen the battery empty icon appears when batteries are low. You are advised to either recharge or renew the batteries within due time.

RESET

If for any reason Sam is not working properly, push the reset button on the bottom.

SAFETY INFORMATION

For your continued safety and the reliability of your clock, please observe the normal electrical safety precautions:

- This product is not a toy. Please ensure that it is kept out of reach of small children and never allow your child to play with either the power unit, the connecting lead or the batteries.
- Keep the product and adapter away from water and moisture. Both intended for indoor use only.
- The clock has been designed to be robust, but it may be broken if dropped.
- The connecting lead is low voltage only, but for reliability reasons it should be treated with care.
- Access to the AC/DC adaptor should not be obstructed whilst in use.
- Electro-static discharge may affect the working of your sleeptrainer. If this occurs, press the reset button.
- The apparatus and AC/DC adaptor shall not be exposed to dripping or splashing and no objects filled with liquids, shall be placed on the clock and AC/DC adaptor.
- For use only with the power supply that came with the sleeptrainer.
- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries.
- **Important! keep for future reference.**

TECHNICAL INFORMATION**Version 2.0**

This ZAZU sleeptrainer is fully compliant with the EU, CA and USA legislation.

When disposing this equipment, please help protect our environment by means of proper disposal. Your local authorities will have special return and disposal facilities available for you.

**Manufactured and distributed by ZAZU**

Postbus 299 | 3740 AG Baarn
The Netherlands
For more information info@zazu-kids.nl

Zazu products

www.zazu-kids.com

**Pam the penguin sleeptrainer**

with nightlight & wireless speaker

**Zoë the penguin sound machine**

with nightlight & wireless speaker

**Sam the lamb sleeptrainer**

with nightlight

**Dex the dog soft toy comforter**

with heartbeat sound

**Lou the owl nightlight**

with sound activation

**Kiki the cat star projector**

with soothing sounds

**Max the monkey soft toy nightlight**


with sounds

**Bobbie the bear sleeptrainer**

with alarm clock

ZAZU**ZAZU****Sam the lamb Sleeptrainer**

with nightlight

**USER GUIDE**

How does the sleeptrainer work?



Night

Time to sleep

At bedtime, Sam will automatically close his eyes, showing your child it is time to sleep.

The display will light up red and can stay lit the entire night or automatically shut off.



Early morning

Just a little longer

30 minutes before the OK to get up time, the display will light up and change to orange colour, indicating that it is almost time to get up.

12 Stars count down the end of bedtime.



OK to get up

OK to get up

At the preset OK to get up time Sam's eyes will open and the display changes to green: OK to get up.

Alarm sound is optional.

THE BASICS

Scroll through the menu by pressing the UP or DOWN button.

SETTINGS MENU



TIME

The current time.



BEDTIME

The time Sam will close his eyes.



'OK TO GET UP' TIME

The time Sam will open his eyes.



SOUND ALARM

- Alarm time
- Volume
- Melody



NIGHTLIGHT

- Brightness
- Auto shut-off: 5-15-30-60 minutes after bedtime or the entire night (CONT).



NAPTIMER

Close Sam's eyes for a specified period: 30-180 minutes.



DEMO FUNCTION

Run a sample night from closing of the eyes to opening of the eyes in only 20 seconds.



Keylock The keylock will automatically activate after 30 seconds. This to prevent children changing the settings. To unlock the keylock press the keylock button for 3 seconds. The lock symbol will disappear from the screen, when successful.

BUTTONS



MENU / STEP BACK

Settings menu/1 step back in menu.



(RE)START SLEEPTRAINING / DOWN

Press 3 seconds to manually close the eyes and/or restart the timer of the night light.




STOP BEDTIME / UP

Press 3 seconds (keylock off) to open the eyes.



KEYLOCK / OK

Press to confirm choice in menu. Press 3 seconds to (un)lock keylock.



Exit menu Leave the menu by pressing the M button.

EN

1ST SET-UP

CONNECT POWER

- Remove the plastic foil from the display.
- Place batteries (4x 1.5 V AA) in the compartment and/or plug in the adaptor.

The menu will now automatically guide you through the necessary items to get Sam up and running:

Note When setting the hours you will scroll passed 24hours setting first and then AM/PM.



SET TIME

- Set the hours with the UP/DOWN button and confirm with OK.
- Set the minutes with the UP/DOWN button and confirm with OK.



SET BEDTIME

- Set the hours with the UP/DOWN button and confirm with OK.
- Set the minutes with the UP/DOWN button and confirm with OK.



SET 'OK TO GET UP' TIME

- Set the hours with the UP/DOWN button and confirm with OK.
- Set the minutes with the UP/DOWN button and confirm with OK.



READY FOR USE

Sam will now show a circle of stars, indicating that Sam is ready for use. Every night Sam will:

- close his eyes at the set bedtime with 15 minutes nightlight.
- open his eyes at the OK-to-get-up time without sound alarm.

Note These are the standard settings for nightlight and soundalarm. They can be changed in the setting-menu, see next page.

GOOD TO KNOW



PRESS 3 SEC.

OPEN SAM'S EYES

Switch off keylock, press the UP button for 3 seconds to open Sam's eyes.



PRESS 3 SEC.

RESTART THE NIGHTLIGHT / CLOSE SAM'S EYES MANUALLY

Every night at set bedtime, Sam will automatically close his eyes and switch ON nightlight according to menu settings. In case nightlight has already switched off when you bring your child to bed, you can manually restart the timer of the nightlight.

Press the DOWN button for 3 seconds to restart timer/close eyes. Display will flash 2 times.

EN

CHANGE SETTINGS

- Press the keylock button for 3 seconds to unlock the keylock.
- Enter the settings menu by pressing the M button.
- Select the icon of which you want to change the settings with the UP/DOWN button.
- Confirm with OK.



CHANGE THE TIME



CHANGE THE BEDTIME



CHANGE 'OK TO GET UP' TIME

- Hours will blink: Change with UP/DOWN button and confirm with OK.
- Minutes will blink: Change with UP/DOWN button and confirm with OK.
- You can now change the alarm time, melody or volume or leave the menu leave the menu by pressing the M-button.

Note When a small alarm bell is displayed in the centre of the screen, the sound alarm is ON.



SET SOUND ALARM

- Press OK to enter the sound alarm sub-menu
- Either the alarm time is displayed, meaning the sound alarm is ON, or OFF is displayed, meaning it is currently switched OFF.
- To switch ON the sound alarm select ON with the UP/DOWN button.
- Press OK.
- Leave the menu by pressing the M button 2x.



ALARM TIME

- Hours will blink: Change with UP/DOWN button and confirm with OK.
- Minutes will blink: Change with UP/DOWN button and confirm with OK.
- Leave the menu by pressing the M button 2x.



WAKE UP MELODY

- Press OK to enter change setting.
- Select the preferred melody with UP/DOWN and confirm with OK.
- Leave the menu by pressing the M button 2x.



Volume

- Press OK to enter change setting.
- Select the preferred volume with UP/DOWN and confirm with OK.
- Leave the menu by pressing the M button 2x.

EN